



SALEEN FRONT SPLITTER
INSTALLATION 2005-07 
MUSTANG



PART# 10-8002-C14092B

SALEEN

Saleen Performance, Inc. 76 Fairbanks Irvine, CA 92618 949-597-4900
www.saleen.com





***IF YOU ARE NOT EXPERIENCED IN THE
AREA OF AUTOMOTIVE MECHANICS,
WE STRONGLY URGE THAT YOU REFER
THIS INSTALLATION TO A CERTIFIED
INSTALLER OR TECHNICIAN***



Obtain the following tools:

Drill 1/8 inch bit

5/16 inch bit

11 mm socket, 1/4" drive

1/4-inch drive ratchet

13 m wrench

Order of Operations:

1. Place the front splitter against the bottom of the 2005-07 Saleen S281 front fascia so that the center mounting extrusions line up with the front of the bottom fascia lip. The ends of the splitter should also be within a few millimeters of being flush with the bottom-rear of the front fascia.(Figures 1-3)



FIGURE 1



FIGURE 2



FIGURE 3

2. Mark hole locations through the splitter, then set the splitter aside. (Figure 4)

3. Drill 1/8 inch pilot holes where marked, then open holes up to 5/16 inch.

4. Place the splitter against the bottom of the front fascia in the proper orientation.

5. Place a small washer (00-9004-C00073*) over each bolt (00-9001-C12037*), and insert the bolt through the splitter and the front fascia.

6. Place a large washer (00-9004-C12039*) over the tip of the bolts, above the inside of the fascia. Thread a nylock nut (00-9003-C06886*) over each bolt. Using an 11mm socket on 1/4" drive to hold the bolt and a 13 mm wrench on the nut, tighten each nut securely.




FIGURE 4