

## INSTALLATION INSTRUCTIONS: SALEEN GRAPHICS FOR 2005-09 MUSTANG

**Tools needed:**

- Glass cleaner
- Water
- Heat gun
- Towels
- Squeegee
- Razor blade

**Order of operations:**

1. The color of the car determines what part number is needed. White cars have the option of blue or black graphics. Non-white cars get silver graphics. The decals start out with the solid chevron followed by the faded chevron.
2. Figure 1 shows the area where the decals go on.
3. First take glass cleaner and clean the area. Dry it off with a cloth diaper.
4. Use a spray bottle with water and saturate the area. This allows the decals to be adjusted easily.
5. Pull the decal apart. Remove one side of the white backing (see Figure 2). Then saturate the area with water.
6. Position the decal as seen in (Figure 3). The corner of the decal must be placed just before the crease in the door.
7. The decal must be centered between the door cladding and the bend in the fender. See figure 3.



Figure 1



Figure 2




Figure 3

8. Use the squeegee to press out any bubbles in the decal.
9. Take the faded chevron and place it 7/8" behind the solid fade. A magnetic template is used (see Figure 4) to make sure the gap is consistent.
10. Repeat steps 3 and 4 to install the faded chevron.
11. See figure 5 for the placement of the fade chevron. Repeat step 8.
12. In order to make sure the chevrons are lined up use a straight edge ruler or measure the gap for the door cladding to the line in the door.
13. Slice the decal in the door opening with a razor blade. Use a heat gun to bend the decal around the door and fender. See figure 6. In order to wrap the decal around the door, open the door and wrap it from the inside. Repeat the same procedure on the left side of the car. Remove the white backing after the decals dry.



Figure 4




Figure 5




Figure 6